

## Technical Newsletter


### NEW FEATURE SHAKER SO-40a ERROR E10 (V07)

**Problem:** Error E10 when can is inside shaker and clampplate doesn't go up.

**Cause:** Can not in the middle of the shaker and/or can dented

**Solution:** By using the "Emergency Stop" and the "UP button" loosen the can

**How:** First press the Emergency Stop, then press the UP button and keep this one pressed, release the Emergency Stop and still keep the UP button pressed. After a few seconds the clampplate will go up.



For more information please contact our Service Department at:

Telephone: 0031-(0)252 240 842

Fax: 0031-(0)252 240 882

E-mail: SERVICE@FLUIDMAN.NL