FLUID MANAGEMENT

SERVICE DEPARTMENT
SASSENHEIM

Technical Newsletter

CONNECTING AGITATION CONTROLLER

Problem: Making connections on a new Agitation controller HA-Large

How: Follow the diagram below.
Connect the secundairy wires parralel (red on red, blue on blue etc)
Connect primairy wires parralel (black on black and grey on grey)

When the transformer has only black wires on the primairy side you can connect it out of fase .
When the fase is not OK the fuse will go out immediately and then you have to changeover one pair of wires.





How cont.: Place the rectifier on the mounting plate with a bolt and a nut M4 x 15

Remarks: There is now an extra fuse in the agitationmotor connection

For more information please contact our Service Department at:
Telephone: 0031-(0)252 240 842
Fax: 0031-(0)252 240 882
E-mail: SERVICE@FLUIDMAN.NL